




DT Roller Press Separator


Part Manual



For Model:


DT 6-Roller Air Press

DT 6-Roller Air Press – Components



Label	Part #	Description
1	X878	1" UHMW Roller Press Guide
2	M498	Rubber lip seal - 1st roller 4-roller press, 1/2" black rubber
3	L246	Rubber lip seal - 2nd roller 4-roller press, 1/2" black rubber
4	M795	Optional Spray Bar – Replacement Nozzle


DT 6-Roller Air Press – Upper & Lower Roller Assembly



Label	Part #	Description
1	G642	8.5in Bellow Air Bag
2	C177	4 Bolt Flange Bearing
3	G586	DT RP Replacement Rubber Roller 48" For 6 RP Only
4	O443	3/8"-16 X 1" SS Bolt
5	B718	5/8"-11 X 3-1/2" SS Bolt
6	Z134	1 HP / 3PH Motor & Gearbox Assembly
7	O443	3/8"-16 X 1" SS Bolt
8	D597	DT RP Replacement Screen Roller 48" For 6 RP Only
9	M619	1/8" SS Screen Wrap Only For 48" Screen Roller
10	P711	4 RP O-lite Bushing 2-1/4" - 3"

*Items not listed are considered non-common replacement parts and can be custom ordered upon request.


DT 6-Roller Air Press - Scraper Assembly




Label	Part #	Description
1	N577	UHMW Screen Scraper
2	S660	6" SS Spring
3	V307	5/16"-18 X 1-½" Carriage Bolt
4	S581	5/16" SS Nut
5	T829	5/16" SS Lock Washer
6	Q797	5/16" SS Flat Washer
7	K895	3/8"-16 X 2" SS Bolt
8	G736	3/8" SS Lock Washer
9	E143	3/8" SS Flat Washer
10	P398	3/8" SS Nut

* Items not listed are considered non-common replacement parts and can be custom ordered upon request.

DT 6-Roller Air Press – Fault Probe Bracket Assembly





DT 6-Roller Air Press – Optional Spray Bar





Label	Part#	Description
1	F534	Optional Spray Bar With Nozzles
2	R455	95-10 Nozzles Only

DT 6-Roller Air Press – Overall Dimensions



DT 6-Roller Air Press – Overall Dimensions



For Technical Support, to order Replacement Parts, or for questions about other products, please
contact your local dealer.
